


//SONORA

Wonderwall



200 eMOTION

Motion TV wall mount
with one arm, for 19"- 42"

EN
INSTALLATION MANUAL




Tools needed (not included)	Hardware (included)
Tape measure	Wall Plate x1
Pencil	Mounting board x1
Drill	Cable Hanger x1
10mm Concrete Drill	
5mm Wood Drill	
Spanner 10mm	
Screwdriver	
Hammer	




STEP1A Brick wall


1a



2a




3a




STEP1B Wood wall


1b



2b





3b




STEP2

Only one screw size fits your TV.


M4 M6 M8




STEP3



STEP4



STEP5









//SONORA Wonderwall 200 eMOTION

Επιτοίχια βάση στήριξης με βραχίονα για τηλεοράσεις LED/LCD από 19" έως 42"


EA

ΟΔΗΓΙΕΣ ΕΓΚΑΤΑΣΤΑΣΗΣ




1ο(A) ΒΗΜΑ Στερέωση της βάσης σε τοίχο με τούβλα ή τσιμέντο


1α



2α




3α




1ο(B) ΒΗΜΑ Στερέωση της βάσης σε ξύλινο τοίχο / γυψοσανίδα


1β



2β




3β




2ο ΒΗΜΑ



M4 M6 M8




Μόνο ένα μέγεθος βίδας ταιριάζει στην τηλεόρασή σας



3ο ΒΗΜΑ



4ο ΒΗΜΑ



5ο ΒΗΜΑ

