


ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ
USER MANUAL

NOD



QUATTRO


Stereo speakers 2.2, 16W

ΕΓΧΕΙΡΙΔΙΟ ΟΔΗΓΙΩΝ

Διαβάστε προσεκτικά τις οδηγίες χρήσης πριν θέσετε τη συσκευή σε λειτουργία και φυλάξτε τις οδηγίες, την απόδειξη και εάν είναι δυνατόν το κουτί με την εσωτερική συσκευασία. Εάν δώσετε τη συσκευή σε τρίτο, παρακαλώ μεταβιβάστε και τις οδηγίες χρήσης.

ΕΠΙΣΚΟΠΗΣΗ ΣΥΣΚΕΥΗΣ

1. Καλώδιο USB
2. Σύνδεση jack 3.5mm
3. Περιστροφικός διακόπτης ρύθμισης έντασης του ήχου
4. Φωτισμός
5. Subwoofer
6. Ηχεία



ΑΠΑΙΤΗΣΕΙΣ ΣΥΣΤΗΜΑΤΟΣ

Κατάλληλη για laptop, H/Y και άλλες συσκευές αναπαραγωγής ήχου που υποστηρίζουν σύνδεση εξόδου ήχου 3.5mm.

ΧΡΗΣΗ ΤΗΣ ΣΥΣΚΕΥΗΣ

1. Διαβάστε προσεκτικά όλες τις οδηγίες και φυλάξτε τις για μελλοντική αναφορά.
2. Αφαιρέστε όλα τα υλικά συσκευασίας και κρατήστε τα μακριά από παιδιά.
3. Αφού αποσυσκευάστε τη συσκευή ελέγχετε για πιθανές βλάβες. Σε περίπτωση βλάβης ή ορατού προβλήματος, μη χρησιμοποιήστε τη συσκευή και απευθυνθείτε στο κατάστημα που το αγοράσατε.
4. Συνδέστε το καλώδιο USB στο λαπτοπ ή στον H/Y.
5. Συνδέστε το καλώδιο jack 3.5mm στην κατάλληλη υποδοχή στον υπολογιστή σας.
6. Περιστρέψτε δεξιόστροφα το διακόπτη για να αυξήσετε την ένταση του ήχου και αριστερόστροφα για να μειώσετε την ένταση του ήχου.

ΚΑΘΑΡΙΣΜΟΣ ΚΑΙ ΣΥΝΤΗΡΗΣΗ

1. Ποτέ μη βυθίζετε τη συσκευή σε νερό ή άλλα υγρά.
2. Σκουπίστε το περίβλημα της συσκευής με ένα μαλακό πανί.

ΑΠΟΘΗΚΕΥΣΗ

1. Αποθηκεύτε πάντα τη συσκευή και το καλώδιο της μακριά από παιδιά.
2. Αποθηκεύτε πάντα τη συσκευή σε ασφαλές και καθαρό μέρος. Για την καλύτερη προστασία της συσκευής, αποθηκεύστε τη μέσα στην αρχική της συσκευασία.


EN

INSTRUCTION MANUAL

Read the operating instructions carefully before putting the appliance into operation and keep the instructions, the receipt and, if possible, the box with the internal packing. If you give this appliance to other people, please also pass on the operating instructions.

PARTS IDENTIFICATION

1. USB cable
2. 3.5mm jack connection
3. ON / OFF Rotary switch & volume adjustment
4. Rainbow effect light
5. Subwoofer
6. Speakers



SYSTEM REQUIREMENTS

Suitable for laptops, PCs and other audio players that support 3.5mm audio output connection.

HOW TO USE

1. Read all instructions carefully and keep them for future reference.
2. Remove all packing materials and keep them away from children.
3. After unpacking the device, check for possible damage. In the event of a fault or visible problem, do not use the device and contact the store where you purchased it.
4. Connect the USB cable to your laptop or PC.

5. Connect the 3.5mm jack cable to computer.
6. Turn the rotary switch clockwise to increase the volume and anti-clock wise to decrease the volume.

CLEANING AND CARE

1. Never immerse device in water or in any other liquid.
2. Wipe the housing of the device with a soft cloth.

STORAGE

1. Always store the device out of the reach of children.
2. Always store the device in a safe and clean place. For the better protection of the device, store it in its original packaging.



Ιωνίας Καλοχώρι, 570 09 Θεσσαλονίκη, Ελλάδα, ΤΗΛ. +30 2310 700.777
Ionias Kalochori, 570 09 Thessaloniki, Greece, TEL. +30 2310 700.777

e-mail: info@sun.gr www.nod.com.gr

