



BEAMZ
MADE
EAZY

152.092 V1.0

IGNITE 400

QUICK START GUIDE

CONTROL MENU

MENU	SUB MENU	SETTINGS	DESCRIPTION
DMX	DMX ADDRESS	001-512	
		Dmx Mode	25CH
SETTINGS	FIXTURE SET	Run Mode	DMX/Host
		Pan Invert	Close/Open
		Tilt Invert	Close/Open
		Dimmer Fast	Close/Open
		No DMX State	Clear/Keep
		Exit	
	DISPLAY	Language	CH/EN
		Display Flip	Close/Open
		Display Mode	60S/Show
		Exit	
	RESET	XY Reset	Cancel/Run
		Motor Reset	Cancel/Run
		All Reset	Cancel/Run
		Factory	Cancel/Run
		Exit	
	EXIT		
INFO	TIME	Current Time	xxxxxH
		Total Time	xxxxxH
		Power Count	xxxxxH
	SENSOR	Pan	
			
	SOFTWARE VERSION	Panel	Vxx.x
		XY	Vxx.x
		Motor	Vxx.x
	EXIT		
MANUAL	PAN	000-255	
	PAN FINE	000-255	
		000-255	
	EXIT		
FACTORY	PASSWORD	000-255	
	PAN	000-255	
	TILT	000-255	
		000-255	
	EXIT		

DMX CHANNELS

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	Pan	000-255	Pan
2	Pan fine	000-255	Pan fine
3	Tilt	000-255	Tilt
4	Tilt fine	000-255	Tilt fine
5	Speed	000-255	P/t speed
6	Macro function	000-199	Reserve
		200-209	Xy reset
		210-219	Effect reset
		220-229	All reset
		230-255	Reserve
7	Shutter	000-003	Closed
		004-103	Strobe slow to fast
		104-107	Open
		108-207	Invert strobe slow to fast
		208-212	Open
		213-251	Random strobe slow - fast
8	Dimmer	000 — 255	Master dimmer
9	Cmy-c	000 — 255	Linear cyan
10	Cmy-m	000 — 255	Linear magenta
11	Cmy-y	000 — 255	Linear yellow
12	Cto	000 — 255	Linear CTO
13	Color wheel	000-004	White
		005-009	White+ Color 1
		010-014	Color 1
		015-019	Color 1+ Color 2
		020-024	Color 2
		025-029	Color 2 + Color 3
		030-034	Color 3
		035-039	Color 3 + Color 4
		040-044	Color 4
		045-049	Color 4 + Color 5
		050-054	Color 5
		055-059	Color 5 + Color 6
		060-064	Color 6
		065-069	Color 6 + Color 7
		070-074	Color 7
		075-079	Color 7 + Color 8
		080-084	Color 8
		085-089	Color 8 + Color 9
		090-170	Fast rotation - slow rotation
		171-174	Stop
		175-255	Slow rotation - fast rotation
14	Gobo wheel 1	000-009	White1
		010-019	White2
		020-029	Gobo 1
		030-039	Gobo 2
		040-049	Gobo 3
		050-059	Gobo 4
		060-069	Gobo 5

		070-079	Gobo 6
		080-089	Gobo 7
		090-099	Gobo 8
		100-109	Gobo 9
		110-119	Gobo 1 jitter
		120-129	Gobo 2 jitter
		130-139	Gobo 3 jitter
		140-149	Gobo 4 jitter
		150-159	Gobo 5 jitter
		160-169	Gobo 6 jitter
		170-179	Gobo 7 jitter
		180-189	Gobo 8 jitter
		190-199	Gobo 9 jitter
		200-225	Fast rotation - slow rotation
		226-229	Stop
		230-255	Slow rotation - fast rotation
15	Gobo wheel 2	000-009	White
		010-019	Gobo 2 -1
		020-029	Gobo 2 -2
		030-039	Gobo 2 -3
		040-049	Gobo 2 -4
		050-059	Gobo 2 -5
		060-069	Gobo 2 -6
		070-079	Gobo 2 -7
		080-089	Gobo 2 -8
		090-099	Gobo 2 -1 jitter
		100-109	Gobo 2 -2 jitter
		110-119	Gobo 2 -3 jitter
		120-129	Gobo 2 -4 jitter
		130-139	Gobo 2 -5 jitter
		140-149	Gobo 2 -6 jitter
		150-159	Gobo 2 -7 jitter
		160-169	Gobo 2 -8 jitter
		170-213	Fast rotation - slow rotation
		214-255	Slow rotation - fast rotation
16	Gobowheel 2 Rotatie	000-127	Linear
		128-190	Fast rotation - slow rotation
		191-192	Stop
		193-255	Slow rotation - fast rotation
17	Prisma 1	000-255	Prism-1
18	Prisma/ rotating	000—127	Rotation
		128—189	Fast rotation - slow rotation
		190—192	Stop
		193—255	Slow rotation - fast rotation
19	Prisma 2	000-255	Prism-2
20	Prisma/ rotating	000—127	Rotation
		128—189	Fast rotation - slow rotation
		190—192	Stop
		193—255	Slow rotation - fast rotation
21	Frost	000—127	Reserve
22		128-255	Frost
		000—255	Focus



23		000—255	Focus fine
24	Zoom	000—255	Linear zoom
25		000—255	Zoom fine



Handwriting practice lines consisting of 25 horizontal dotted lines.



Handwriting practice lines consisting of 20 horizontal dotted lines.



BEAMZ

YOUR FUTURE
YOUR SKILLS
YOUR PLATFORM
YOUR PARTY
YOUR EVENT

 **beamZ^{Pro}**

offers a wide range of high performance lighting equipment and related accessories for the rental, entertainment and architectural lighting markets. BeamZ Pro stands for performance, innovation and value pricing!



BEAMZLIGHTING.COM