



MIXtouch8

USER GUIDE H10991 - Version 1 / 10-2018

1 - Safety information

Important safety information



This product contains non-isolated electrical components. Do not undertake any maintenance operation when it is switched on as it may result in electric shock.



This unit is intended for indoor use only. Do not use it in a wet, or extremely cold/hot locations. Failure to follow these safety instructions could result in fire, electric shock, injury, or damage to this product or other property.



Any maintenance procedure must be performed by a CONTEST authorised technical service. Basic cleaning operations must thoroughly follow our safety instructions.

Symbols used



This symbol signals an important safety precaution.



WARNING

The CAUTION symbol signals a risk of product deterioration.

The WARNING symbol signals a risk to the user's physical integrity. The product may also be damaged.

Instructions and recommendations

1 - Please read carefully :

We strongly recommend to read carefully and understand the safety instructions before attempting to operate this unit.

2 - Please keep this manual :

We strongly recommend to keep this manual with the unit for future reference.

- 3 Operate carefully this product :
- We strongly recommend to take into consideration every safety instruction.

4 - Follow the instructions:

Please carefully follow each safety instruction to avoid any physical harm or property damage.

5 - Avoid water and wet locations :

Do not use this product in rain, or near washbasins or other wet locations.

6 - Installation :

We strongly encourage you to only use a fixation system or support recommended by the manufacturer or supplied with this product. Carefully follow the installation instructions and use the adequate tools.

Always ensure this unit is firmly fixed to avoid vibration and slipping while operating as it may result in physical injury.

7 - Ceiling or wall installation :

Please contact your local dealer before attempting any ceiling or wall installation. 8 - Ventilation :

The cooling vents ensure a safe use of this product, and avoid any overheating risk. Do not obstruct or cover these vents as it may result in overheating and potential physical injury or product damage. This product should never been operated in a closed non-ventilated area such as a flight case or a rack, unless cooling vents are provided for the purpose.

9 - Heat exposure :

Sustained contact or proximity with warm surfaces may cause overheating and product damages. Please keep this product away from any heat source such as a heaters, amplifiers, hot plates, etc...



WARNING: This unit contains no user-serviceable parts. Do not open the housing or attempt any maintenance by yourself. In the unlikely even your unit may require service, please contact your nearest dealer.

In order to avoid any electrical malfunction, please do not use any multi-socket, power cord extension or connecting system without making sure they are perfectly isolated and present no defect.

Sound levels



Our audio solutions deliver important sound pressure levels (SPL) that can be harmful to human health when exposed during long periods. Please do not stay in close proximity of operating speakers.

Recycling your device



• As HITMUSIC is really involved in the environmental cause, we only commercialise clean, ROHS compliant products.

• When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

10 - Electric power supply :

This product can only be operated according to a very specific voltage. These information are specified on the label located at the rear of the product. **11 - Power cords protection:**

Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at lugs, convenience receptacles and the point where they exit from the fixture. **12 - Cleaning precautions :**

Unplug the product before attempting any cleaning operation. This product should be cleaned only with accessories recommended by the manufacturer. Use a damp cloth to clean the surface. Do not wash this product.

13 - Long periods of non use :

Disconnect the unit's main power during long periods of non use.

14 - Liquids or objects penetration :

Do not let any object penetrate this product as it may result in electric shock or fire. Never spill any liquid on this product as it may infiltrate the electronic components and result in electric shock or fire.

15 - This product should be serviced when :

Please contact the qualified service personnel if :

- The power cord or the plug has been damaged.
- Objects have fallen or liquid has been spilled into the appliance.
- The appliance has been exposed to rain or water.
- The product does not appear to operate normally.
- The product has been damaged.

16 - Inspection/maintenance :

Please do not attempt any inspection or maintenance by yourself. Refer all servicing to qualified personnel.

17 - Operating environment :

Ambient temperature and humidity: +5 - +35°C, relative humidity must be less than 85% (when cooling vents are not obstructed).

Do not operate this product in a non-ventilated, very humid or warm place.

2 - General and technical data

Connectivity

Mic inputs	4 on XLR chassis + 2 on combo chassis
Line input	1 sur 2 châssis Jack 6.35 et mini Jack 3.5
Master output	1 on 2 XLR chassis
AUX output	2 on 2 6.35 Jack chassis
Footswitch	2 on 2 6.35 Jack 6.35
Pre-listening	1 on Jack 6.35

Technical specifications

Line input impedance	3ΚΩ
Line input impedance	20ΚΩ
Output impedance	470Ω
Impedance of the headphone output	100Ω
Residual bus noise	-90dBU
Maximum bus power	+18dBU
Maximum voltage gain	80dB input to output
Dynamic range	106dBU (20Hz~20kHz)
AD / DA	24 bits max / 192kHz
Signal processing	40-bit floating-point processor
Signal latency	<1.8msec input to output
Phantom power supply	48V, each channel can be switched individually
Crosstalk(@1KHz)	-85 dB
USB interface	2 USB2.0 interface, maximum 32G supported, can be used for USB disk playback and recording, support WAV, MP3 format
Network	WIFI connecting to USB wireless module, 1 LAN interface
Effects	2 Reverb and 2 Delay
Power supply	12V via adaptateur secteur (AC 100-240V, 50/60Hz)

Contents of the package The MIXtouch8 console 1 External power supply 1 IEC power cord 1 WiFi dongle The user guide

3 - Overview of the unit

3-1 Front panel



- **1-** 4 microphone inputs on XLR chassis
- 2- 2 microphone inputs on combo chassis
- 3- Stereo inputs on 6.35" Jack chassis
- 4- Stereo input on 3.5 jack
- 5- Auxiliary output on chassis Jack 6.35
- 6- Footswitch connector on chassis Jack 6.35
- 7- USB port for song playback, recording or connecting a WIFI dongle
- 8- Master output on XLR chassis
- 9- Pre-listening output on 6.35 Jack chassis with level adjustment
- **10-**Power On Button: Press and hold this button, it flashes when the console is started and then stays on when the console is ready.
- 11-MUTE button: Stops the playback of songs on USB storage equipment
- **12-**PLAY button: Used to start the playback of songs
- 13-Multi-function knob
- 14-Vu-meter of the general output level
- 15-Vu-meter of the level of the inputs
- 16-Indicator of the active channel
- 17-Channel Selector: The channel selection is made each time this button is pressed
- 18-Microphone channels gain potentiometers

3-2 Rear Panel



19-Power supply input: 12V DC

20-USB connector for song playback, recording or connecting a WIFI dongle

21-Switch to return to factory settings

22-RJ45 port to connect the console to the network

4 - Connection to the controller

4-1 Connection via the wired network



4-2 HotSpot connection

	Settings			WI-FI	
Appl	e ID Suggestions	2 >			
63	Airplane Mode	0		Wi-Fi	
-	, a pano modo	\mathcal{Q}	~	MIXIOUCh8-01 Unsecured Network	\$ (i)
2	Wi-Fi	MIXtouch8-01			
*	Bluetooth	On	CH	IOOSE A NETWORK	
VEN	VPN	0		GLS-WLAN-MOBIL	≜ ≑ ()
-		\sim		HITMUSIC Showroom	≗ ≎ 🕕
6	Notifications			HITMUSIC Showroom_5G	ê 🗢 🛈
4 3)	Sounds			HitmusicLogistique	≞ ≎ ()
G	Do Not Disturb			PUBLIC-2	ê 🗢 🛈
Ξ	Screen Time			WIFI2	₽ ≈ ()
				WIFI2-5	∎ ≑ ()
Θ	General			Wifi2-B	≜ ≉ 🕕
8	Control Centre			Other	
A.A.	Display & Brightness				-
	Wallpaper		As	sk to Join Networks	\odot
	Siri & Search		Kn ma	own networks will be joined automatically. If no known networks are available, mually select a network.	you will have to

Activate the WiFi connection of your computer or other types of devices (tablet, mobile phone,...etc). Select the MIXtouch8 console from the list and connect it.

Open an Internet browser and type in the address: 10.10.10.2.1

Note: If in a previous session you changed the console address, type the address you changed.

5 - Adjusting network settings

5-1 - To access the settings click on the settings tab (at the bottom of the left menu) then on the "**Network**" tab then finally on the "**Setup**" button. You are then asked to authenticate yourself. The username and password are both "admin".

5-2 - Click on "Sign In" to access the settings page.

$\frac{10:15:47}{2019.08.20}$	General	etwork	.og Group Setup	Foot Switch
Copy Paste	Setup			
Monitor Play				
Meter	Identity	euthentication		
FX	(Johns)	authentication		
Sciences	Userna	me: admin		
Mute Group	Passwo	rd:		
IN ;			Cancel	
AUX				
•				

5-3 - Select "**Network**" and go to the "**LAN Configuration**" page. You can display the IP address of the console or change it manually. In the same network, type this IP address into the browser of the control device (PC) to connect and control the console

10:16:19 2019.08.20	General Network Log Group Setup Foot Switch
Copy Paste	Network Configuration LAN Configuration Administrator Password Network State
Monitor Play	LAN
Meter	Please power cycle the mixer after changing the parameters on this page. Address
FX	DHCP Manual
Scenes	IP
	10.10.1.1
Mute Group	Netmask
N	255.255.255.0
	Gateway
AUX	10.10.1.1
•	

5-4 - Select the "**Administrator Password**" tab to access the administrator password configuration page. You can change the login password.

10:28:37 2019.08.20	General Network Log Group Setup Foot Switch
Copy Paste	Network Configuration LAN Configuration Administrator Password Network State
Monitor Play	Administrator Password
Meter	Change the UI administrator password. If you forget this password you will have to reset the UI hardware. Current
FX	Current Admin Password
Scenes	New
	New Admin Password
Mute Group	Confirm
N	Confirm New Admin Password
AUX	

5-5 - Select the "Network Configuration" tab to access the wireless network settings page.

The wireless network settings are divided into two parts HOTSPOT and WIFI.

You can only choose to activate one of the two connection modes. Activating the WIFI automatically disables HotSpot. If you connect via a HotSpot, you will disconnect the console. It is recommended to use either one or the other, and to change only the IP address of one of the two connection modes, always keeping one connection mode as the default mode.



5-6 - Select the "Network State" tab to view all network configurations

17:02:43 2019.08.21	General Network	Log Group Setup Foot Switch	
Copy Paste	Network Configuration	LAN Contiguration Administrator Password	Network State
Monitor Play	Network State		
Meter	HotSpot	Wi-Fi	LAN
FX	ENABLED UP SSID: MIXtouch8-01 IP: 10.10.2.1	DISABLED DOWN	IP: 10.10.1.1 Netmask: 255.255.255.0 Gateway: 10.10.1.1
Scenes			
Mute Group			
N			
AUX			
•			

5-7 - Restore the factory settings.

When the console is on, press and hold the UBOOT switch under the rear panel for more than 3 seconds. A window appears asking you to confirm the return to the factory settings.

If you confirm, the console will restart.



6 - Mixing functions

6-1 - Input channels main page

Accessible via the "IN" button in the left menu, this page allows you to select the channels to access their settings.

13:57:46 2019:08:20	Input Stag	EC	Dy	namics	Send				L/R
Copy Paste	CH1	CH2	СНЗ	CH4	СН5	СН6	ST	┏	GEQ
Monitor Play	Solo	Solo	Sala	Sala	Salo	Salo	Sala		Solo
Meter	-11-	-0-	-0-	-0-	-0-	-0-		-	
FX	10	10	10	10	10	10	10	П	
Scenes	0	0	0	o	o	0	0		
Mute Group	-10	-10	-10	-10	-10	-10	-10		-10
AUX									
•	-60.0						-80	G	-60.0
	Mute	Mute	Mute	Mute	Mute	Mute	Mute	N	Mute

6-2 - Accessing auxiliary channels

Click on "**AUX**", the right window appears as shown in the image. The display of the right channels can also be done by dragging the window.



6-3 - Customize the channel display

By clicking on the channel name (at the top of the channel), you can change its name and color.

15:34:26 2019.08:20	Input Stage	EO	Dyn	amics	Send				
Copy Paste	CH1	CH2	СНЗ	CH4	CH5	CH6	ST	Р	GEQ
Monitor Play	Solo	Cala	Colo	Gain	Colo	Solo	Solo	-	
Meter	-11-	Please d	hoose a chan	nel name and	colour	-0-	-0-	-	
FX						10	10		
Scenes									
Mate Group							, is		
IN	ac					-10	-10		
AUX			Cancel						
•	-80.0								
	6	0	0	—			-50		
	Mute	Mute	Mute	Mute	Mute	Mute	Mute	N	

6-4 - Input stage

When a channel is selected, click on "Input Stage" to activate phantom power, phase inverter and set the delay for that channel.



6-5 - The equalization section

When a channel is selected, click on "**EQ**" to access the equalizer settings. You then have four adjustment points that you can drag on the screen. You can also use the potentiometers to make your settings.



- Bypass : Disables equalization without changing settings
- Library : Allows you to save and access the files in the parameter library.
- Save : Save the settings in the library
- **HPF** : Activates the high-pass filter
- $\ensuremath{\textit{Freq}}$: Allows you to select the frequency on which the setting acts
- Gain : Allows you to adjust the level
- **Q** : Sets the width of the band on which the setting acts

6-6 - Dynamic processing

When a channel is selected, click on "Dynamics" to access the Gate and compressor settings.



Bypass : Disables the compressor and gate without changing the settings

Library : Allows you to save and access the files in the parameter library

Save : Save the settings in the library

Side Chain : Allows you to link another channel to the current channel settings

6-7 - When a channel is selected, click on "Send" to access the bus settings.

This section allows you to manage the buses to which the signal present on the current channel is sent.



6-8 - The Monitor/Signal Generator function

Click on the "**Monitor**" button in the left menu to access this section. In this section is the level adjustment of the monitor output and the signal generator.

Only channels for which the "Solo" button is active (green) are sent to the Monitor output.



6-9 - The playback and recording function

Click on the "**Play**" button in the left menu to access this section. This section allows you to manage the playback of songs on USB storage media.

It also allows you to record the current mix on a USB storage medium.

15:37:32 2019.08.20	Playlist	Record Playback
Copy Paste Monitor Play	No data	
Meter FX		
Scenes		
Mute Group		
AUX	00:00	
		•

6-9 - The measurement function

Click on the "Meter" button in the left menu to access this section. This section allows you to view all incoming and outgoing levels.



6-10 - The effects

Click on the "FX" button in the left menu to access this section. This section allows you to adjust the 4 available effects. These effects can be assigned to the outputs.

6-10-1 - Reverbs 1 and 2

Click on the "Reverb1" or "Reverb2" button to access the settings.



6-10-2 - Delay 1 and 2

Click on the "Delay1" or "Delay2" button to access the settings.



6-10 - The copy/paste function

This function allows you to copy the settings from one channel to another.

Select the channel whose settings you want to copy, click on "**Copy**" then select the destination channel and click on "**Paste**".



6-10 - Backup management

To access this function, click on "Scenes" in the left menu.

This function allows you to save, record, delete, rename, export and import scenes.

The scenes correspond to the current settings of the console.

15:38:30 2019.08.20	Scene list		
	Seg No	Name	
Copy Paste		No data	
Monitor Play			
Meter			Delete Rename
FX			
Scenes			Copy New
Hate Oreur			
mute Group			Save Load
AUX			Export Export
		Prev Next	

7 - Additional settings and functions

To access this section, click on the button ______ at the bottom of the left menu.

7-1 - General settings: "General"

This section allows you to choose the language of the system, update it and restore the factory settings.



7-2 - Network settings: "Network"

This section has been treated in paragraph 5.

7-3 - Session storage: "Log"

This function allows you to retrieve system information from USB media.



7-3 - Group management: "Group Setup"

This function allows you to create a group of channels. These channels will be "**mutated**" when you click on the "**Mute Group**" button

15:40:24 2019.08.20	General	Netwo	xik	Log	Group Seli	Foot Switch
Copy Paste	Clear	Y	All	l.		
Monitor Play						
Mater	CH1	CH2	СНЗ	CH4	CH5	СН6
	ST	PLAY	REVERB1	REVERB2	DELAY1	DELAY2
FX	AUX1	AUX2				
Scenes	L/R					
Mute Group						
N						
AUX						
•						

7-4 - Assignment of footswitch: "Foot Switch"

This function allows you to assign one or more effects to each foots witch so that they can be triggered remotely. The pedals are in fact simple dry and permanent contact switches.

15:40:41 2019.08.20	General Network Log Group Setup Foot Switch
Copy Paste	Foot Switch1 Foot Switch2
Monitor Play	
Meter	REVERBI REVERB2 DELAYI DELAY2
FX	
Scenes	
Mute Group	
IN	
AUX	
\odot	

Because AUDIOPHONY[®] takes the utmost care in its products to make sure you only get the best possible quality, our products are subjects to modifications without prior notice. That is why technical specifications and the products physical configuration might differ from the illustrations.

Make sure you get the latest news and updates about the AUDIOPHONY[®] products on www.audiophony.com AUDIOPHONY[®] is a trademark of HITMUSIC S.A.S - Parc d'Activités Cahors Sud – En Teste - 46230 FONTANES - FRANCE